



## HDMI : LVDS Interface



Pin 14, 15 - DSD/PCM signal

DSD/PCM = High ; DSD input mode

DSD/PCM = Low ; PCM input mode



	I2S	DSD
Pin 1	SD-	DSD_R-
Pin 2	GND	GND
Pin 3	SD+	DSD_R+
Pin 4	BCLK+	DSD_BCLK+
Pin 5	GND	GND
Pin 6	BCLK-	DSD_BCLK-
Pin 7	LRCK-	DSD_L-
Pin 8	GND	GND
Pin 9	LRCK+	DSD_L+
Pin 10	MCLK+	.
Pin 11	GND	GND
Pin 12	MCLK-	.
Pin 13	Not Used	Not Uesd
Pin 14	DSD/PCM	DSD/PCM
Pin 15	DSD/PCM	DSD/PCM
Pin 16	Not Used	Not Uesd
Pin 17	GND	GND
Pin 18	Not Used	Not Uesd
Pin 19	GND	GND